


Indoor Localisation



Institute of Medical Informatics
University of Lübeck

Contents

1. Project presentation

- About indoor localization
- Project general description

2. Basic step estimator

- Data acquisition
- Step detection in accelerometer data
- Angular integration with accelerometer and gyroscope data
- Plotting of the estimated tracks

3. Data acquisition protocol

4. Organisation of scenario 2

- Objectives of the project
- Project organisation
- Project evaluation
- Advised checklists


1. Project presentation

About Indoor Localisation

- **Goal:** localise moving objects/people in an indoor environment using wearable devices
- Tracking people in an indoor environment is a difficult task:
 - GPS not working well indoors
 - Few sensor devices available, mostly smartphone-based
 - Factors can affect the quality of the recorded data (e.g. movements of the sensors in addition to the movement of the person)
- Main solutions = probabilistic approaches:
 - Based on estimating a state, and correcting the estimation based on observations
 - E.g. Kalman filter, particle filter, ...

Project general description

- Obtaining a good indoor tracker is a complex and time consuming task (e.g. Kalman filtering, particle filtering, ...)
- Scenario 2 = Python programming of a "simple" **step estimator** using smartphone accelerometer and gyroscope data
- In this scenario, no use of external information (e.g. floor plan, position of obstacles, ... etc)



Estimated track



Real track


2. Basic step estimator

Principle of a basic step estimator

- Process in **three main steps**:
 - Accelerometer and gyroscope data acquisition
 - Step detection in accelerometer data
 - Angle estimation in gyroscopic data
- Once estimated, steps and angles can be plotted and (theoretically) compared to some ground truth to check
- **Note**: acquiring accurate indoors ground truth is complex and time-consuming → it will not be done in this project

Data acquisition (1/2)

- Data acquired using a smartphone with accelerometer and gyroscope sensors
- To acquire data, possibility to use the following apps:
 - **Android:**
 - [Physics Toolbox Sensor Suite](#)
 - [Phyphox](#)
 - Other?
 - **iOS:** ? (Good apps available, but most are paying only)



**Physics Toolbox
Sensor Suite
(Android)**


Data acquisition (2/2)

About the Physics Toolbox Sensor Suite (Android):

- How to record data from several sensors simultaneously:
 - Open the menu by tapping the top left \equiv icon
 - Select "Multi record"
 - Select the sensors you want to record
 - Tap the \oplus sign to start the recording
 - Tap the \blacksquare sign to stop the recording
 - Save the record under the CSV format
- **Notes:**
 - the accelerometer sensor is called "G-Force meter"
 - data are saved on the smartphone SD card. The app gives the option to export them (e.g. via e-mail)
- The data acquisition protocol will be specified in the next slides

Step detection using accelerometer data (1/3)

- Analysis of accelerometer data to detect steps
- One step = one peak in the signal
- Only using the norm of the acceleration is enough



a_x

a_y


a_z

$\|a\|$


Acceleration data acquired while walking

Step detection using accelerometer data (2/3)

- **Goal:** detect peaks in the acceleration signal and their beginning/end
- Sounds simple, but actually difficult because many **challenges:**
 - How to define a peak? What is the threshold? when it begins or ends?
 - What methods to use to detect a peak?
 - How to reduce the effect of noise?



Peak detection on raw signal



Peak detection on smoothed signal

Step detection using accelerometer data (3/3)

- Two steps to consider:
 - Noise removal (pre-processing)
 - Peak detection
- The choice of methods for those two steps is up to you
- Some possibilities ... :
 - ... for noise removal:
 - Low pass filter
 - Moving average
 - Others?
 - ... for peak detection:
 - `scipy.signal.find_peaks(...)`
 - Smoothed z-score peak detection
 - Others?


Angular integration using gyroscope data (1/6)

- **Goal:** detect the turning angle Θ of the subject at each step using angular velocity data provided by the smartphone
- **Theory:** if you have the angular velocity $\omega = \frac{d\theta}{dt}$, obtaining Θ is only a matter of temporal integration, i.e.

$$\theta_t = \int_0^t \omega(k) dk$$

or in the discrete case:

$$\theta(k) \approx \sum_{n=1}^k \omega(n-1) \cdot \Delta t$$



- In practice, not that easy because Θ and ω are not measured in the same basis!


Angular integration using gyroscope data (2/6)

- To solve this issue:
 - Find the matrix \mathbb{R} of rotation between basis \mathbb{B} and \mathbb{B}'
 - Multiply the gyroscope readings by the matrix \mathbb{R}^{-1}
 - Integrate the readings over time to get the angle
- How to determine \mathbb{R} ?
 - By using the accelerometer to determine the relation between the gravity vector $\vec{g}_B = (0, 0, 9.81)^T$ and $\vec{g}_{B'}$
 - If $\vec{g}_{B'}$ is available, it is possible to define \mathbb{R} as follows:
 - $\vec{u}_z \stackrel{\text{def}}{=} \vec{g}_{B'}$
 - $\vec{u}_x \stackrel{\text{def}}{=} (0, 1, 0)^T \wedge \vec{u}_z$
 - $\vec{u}_y \stackrel{\text{def}}{=} \vec{u}_z \wedge \vec{u}_x$
 - $R \stackrel{\text{def}}{=} \left[\frac{\vec{u}_x}{\|\vec{u}_x\|}, \frac{\vec{u}_y}{\|\vec{u}_y\|}, \frac{\vec{u}_z}{\|\vec{u}_z\|} \right] \in \mathcal{M}_{3 \times 3}(\mathbb{R})$

with the \wedge operator denoting the cross product

Angular integration using gyroscope data (3/6)

- Both \vec{g}_B and $\vec{g}_{B'}$ can be obtained by **keeping the smartphone still** in their respective basis B and B'



**Phone on a flat
surface (B)**


**Inclined
phone (B')**

- Note:** assumption = B' remains unchanged during the data acquisition, i.e. the phone orientation is kept the same.

Angular integration using gyroscope data (4/6)

To get an estimation of the components of $\overrightarrow{g_{B'}}$:

- Record accelerometer data while keeping the phone in the same orientation that will be used for the data acquisition
- Estimate each component by averaging the data values acquired
- Possibility to smooth the acquired data before averaging (e.g. with a low-pass filter) for a better estimation



$$\overrightarrow{g_{B'}} = \begin{pmatrix} g_{x'} \\ g_{y'} \\ g_{z'} \end{pmatrix} \simeq \begin{pmatrix} \text{average}(\text{green}) \\ \text{average}(\text{red}) \\ \text{average}(\text{blue}) \end{pmatrix}$$

Angular integration using gyroscope data (5/6)

- In practice, the orientation of the phone doesn't always remain the same, so \mathbb{R} must be recomputed at all times to improve the estimation accuracy.
- Updating $\overrightarrow{g_{B'}}$ can be easily done by using a moving average with a low-pass filter:

$$\forall t \geq 0, \overrightarrow{g_{B'}}(t) = \begin{cases} \overrightarrow{g_0} & \text{if } t = 0 \\ \mu \times \overrightarrow{g_{B'}}(t-1) + (1-\mu) \times \vec{a}(t) & \text{else} \end{cases}$$

with

- $\overrightarrow{g_0} \stackrel{\text{def}}{=} \overrightarrow{g_{B'}} \in \mathbb{R}^3$ (c.f. previous slide)
- $\vec{a}(t) \in \mathbb{R}^3$ acceleration returned by the smartphone at time t
- $\mu \in [0.5, 1[$ constant (e.g. $\mu = 0.9$)

Angular integration using gyroscope data (6/6)

- The projected turn rate is given by $\frac{\partial \theta}{\partial t}(t) = [R^{-1}(t)\omega(t)]_z \stackrel{\text{def}}{=} \dot{\Theta}_z(t)$
 - **Note:** R orthogonal matrix $\Rightarrow R^{-1} = R^T$
- Integrating the projected turn rate yields the estimated turning angle $\Theta(t)$ at time t :

$$\Theta(t) \simeq \sum_{k=1}^t \dot{\Theta}_z(k) \times \Delta t$$

with Δt interval of time between two consecutive sensor readings.

- **Note:** the accuracy on the value of Δt is highly impactful on the precision of the final results

Plotting estimated tracks

- Plotting of the estimated track possible after getting the results of the step estimation + estimated turning angles
- Let (x_t, y_t) = position of the subject in the plane (\widehat{xOy}) , λ_t = step length, and θ_t = estimated turning angle at time t . Then:
 - $x_{t+1} = x_t + \lambda_t \times \cos \theta_t$
 - $y_{t+1} = y_t + \lambda_t \times \sin \theta_t$
- **Note:** estimating the length of each step is a (very) difficult problem. It is easier to take $\forall t, \lambda_t = \lambda$, with λ constant. Usually, $\lambda \in [70, 80]$ *cm*.


3. Data acquisition protocol

Data acquisition experimental protocol (1/2)

- Data acquisition: used to be in building 64
- Under the new regulations: any closed track with characteristic shape should be fine (e.g. outline of a flat, square, ...)
- Device: hand-held smartphone with accelerometer and gyroscope

- **Experimental protocol:**

- Choose starting position and orientation
- Choose starting orientation of the smartphone
- Start recording data
 - Stay idle for 5-10 seconds
 - Move along the track while keeping the same phone orientation
 - End the walk at the same position and with the same orientation than the start
- Stop recording data



Data acquisition experimental protocol (2/2)

- **Note:** no acquisition of ground truth data in the experimental protocol, so no rigorous evaluation of the results.
- **Optional:**
 - If you are acquiring data outside: GPS
 - Number of steps count
- **Pieces of advice:**
 - Walk normally, no need to exaggerate steps
 - Try to keep the phone orientation the same
 - Try to acquire 2-3 tracks

4. Organisation of scenario 2

Objectives of the project

- **Objectives:**
 - Acquire data following the experimental protocol
 - Program a step estimator using accelerometer and gyroscope data in Python
 - Plot the estimated tracks
- **Constraint:**
 - Data acquisition must follow the specified protocol
- **Additional specifications:**
 - None

Project organisation

- Same group organisation as the first scenario
- Advised milestones:
 - **1st week:** data acquisition and pre-processing
 - **2nd week:** step detection in accelerometer data
 - **3rd week:** turning angle estimation with accelerometer and gyroscope data
 - **4th week:** finalization of the previous steps, step estimation plotting and report writing

Project evaluation

For the second scenario about indoor localisation:

- **Solution** = Python code which implements the step estimator, i.e. step detection, angle estimation and plotting
- What is expected to be in the report at minima:
 - Description of the methods used for the different steps of the project
 - Overall description of your Python implementation
 - Plot(s) of the estimated track(s)
 - Small analysis of the estimated tracks you obtained (i.e. were the results satisfying? What could have been improved?)
- The structure and length of the report are up to you.

Advised checklist for week 1

- Discuss group organisation
- Check how to use the data acquisition app
- Acquire data.
 - Performing several data acquisition rounds can ensure you get data of quality good enough to be worked on.
- Check how to convert CSV to a data type suitable for Python analysis (e.g. numpy array)
- Check if data pre-processing is needed
- Write Python data (pre-)processing scripts
- Write data plotting scripts

Advised checklist for week 2

- Check which pre-processing and peak detection Python methods to test
- Plot the results of the peak detection to make sure that the results are plausible
- Try to find the optimal hyper-parameters of your peak detection method
- **Note:** the best approaches for peak detection and pre-processing might depend on the data acquired by your smartphone (sampling rate, quality, ...). Testing different approaches is advised.

Advised checklist for week 3

- Determine the matrix and change of basis $\mathbf{R}(0)$ by using the accelerometer data acquired at the beginning of the protocol
- Write a script to obtain the matrix of change of basis \mathbf{R} at any time t
- Write a Python script for angle estimation using gyroscope data
- Write a Python script plotting the estimated track given estimated angles
- **Note:** the gyroscope provides readings using radians

$$1 \text{ rad} = \frac{\pi}{180} \text{ degree}$$